

## Forward Port Linksys WRT54G

Linksys WRT54G WRT54GS, WRT54GL WRTSL54GS

1. เอา UPnP ออกจาก โปรแกรม Bit : Preferences -> advanced -> Connections
2. add Program + Port ที่ Firewall (หากปิดอยู่ก็ไม่ต้องสนใจครับ)

สมมติ ว่าใน โปรแกรม Bit ของเรา คือ port 12345

เข้า <http://192.168.1.1/>

username : admin

password : admin

หรือ

username : true

password : true

หรือ

username : admin

password : TTT

หรือ

username : admin

password : tot

ที่เมนูด้านบน Setup Wireless Security .....

กดเข้าไปที่ Security



ในส่วนของ Firewall

ให้เอา ต๊กหน้า Block Anonymous Internet Requests ออก

แล้วกดปุ่ม Save Settings



กดที่เมนู Applications & Gaming ด้านบน (แถวเดียวกับ Security)

จะเห็น เมนู Port Range Forwarding ใต้ Applications & Gaming

LINKSYS®  
A Division of Cisco Systems, Inc. Firmware Version

Wireless-G Broadband Router WRT

**Applications & Gaming**

Setup | Wireless | Security | Access Restrictions | **Applications & Gaming** | Administration

Port Range Forward | Port Triggering | DMZ | QoS

**Port Range Forward**

Port Range					
Application	Start	End	Protocol	IP Address	Enable
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>
	0	to 0	Both	192.168.1.0	<input type="checkbox"/>

**Port Range Forward**  
Certain applications may require you to open specific ports on your router for it to function correctly. Examples of these applications include servers and certain online games. When a request for a certain port comes from the internet, the router forwards the data to the computer you specify. Due to security concerns, you may want to restrict port forwarding to only the ports you are using, and uncheck the **Enable** checkbox after you are finished. [More...](#)

Cisco

Save Settings | Cancel Changes

1. **Application** : จะใส่ทำอะไรก็ได้ ที่บ่งบอกว่าเราใช้รายการนี้กับโปรแกรมอะไร
  2. **Start** : 12000 (โปรแกรมบิต Port : 12345)
  3. **End** : 12500 (โปรแกรมบิต Port : 12345)
  4. **Protocol** : Both
  5. **IP Address** : ใส่เลข LAN IP ของเราลงไป ดูวิธีด้านล่าง
  6. **Enabled** : ตีกล่องรายการที่เราทำไว้ครับ
- กดปุ่ม Save Settings เป็นอันเสร็จครับ

วิธีหา ip address ของเครื่องเรากลับ

ทำได้ โดย กดปุ่ม start (windows) กดที่ run

พิมพ์ cmd กด enter

มาไฟล์ที่หน้าต่าง ms-dos

พิมพ์ ipconfig

```
C:\WINDOWS\system32\command.com

C:\>ipconfig /all

Windows IP Configuration

    Host Name . . . . . : betty
    Primary Dns Suffix . . . . . :
    Node Type . . . . . : Unknown
    IP Routing Enabled. . . . . : No
    WINS Proxy Enabled. . . . . : No

Ethernet adapter Local Area Connection 4:

    Connection-specific DNS Suffix . :
    Description . . . . . : Realtek RTL8139 Family PCI Fast Ethernet NIC
    Physical Address. . . . . : 00-30-BD-28-C5-40
    Dhcp Enabled. . . . . : No
    IP Address. . . . . : 192.168.1.2
    Subnet Mask . . . . . : 255.255.255.0
    Default Gateway . . . . . : 192.168.1.1
    DNS Servers . . . . . : 216.104.64.5
                          : 216.104.72.5

C:\>
```

ดูที่ ip address คับ 192.168.1.x (ตามตัวอย่าง x เป็นเลข 2)

ขอบคุณ <http://a-forwardport.blogspot.com/2009/02/forward-port-linksys-wrt54g.html>

, <http://portforward.com>